



Navhouse Corporation
 10 Loring Drive
 Bolton, Ontario, Canada L7E 1J9
 905-857-8102
 Contact:

Julie D'Ettorre Customer Service Manager

LRU Repair/Overhaul Capability List 2017

System P/N	Description	Product	Key Word	OEM
HG1050AC09	Inertial Reference Unit	HG1050	IRU	Honeywell
HG1050AC10	Inertial Reference Unit	HG1050	IRU	Honeywell
HG1050AC11	Inertial Reference Unit	HG1050	IRU	Honeywell
HG1050AD09	Inertial Reference Unit	HG1050	IRU	Honeywell
HG1050AD10	Inertial Reference Unit	HG1050	IRU	Honeywell
HG1050AD11	Inertial Reference Unit	HG1050	IRU	Honeywell
HG1050AE09	Inertial Reference Unit	HG1050	IRU	Honeywell
HG1050AE10	Inertial Reference Unit	HG1050	IRU	Honeywell
HG1050AE11	Inertial Reference Unit	HG1050	IRU	Honeywell
HG1103	Inertial Reference Unit	HG1103	IRU	Honeywell
HG2030	Inertial Reference Unit	HG2030	IRU	Honeywell
HG2001	Inertial Reference Unit	HG2001	IRU	Honeywell
451190-03	LTN 58 Mode Select Unit	LTN51	MSU	Litton
451985-04	LTN-58 Inertial Navigation Unit	LTN58	INU	Litton
451985-04-02	LTN-58 Inertial Navigation Unit	LTN58	INU	Litton
451985-04-06	LTN-58 Inertial Navigation Unit	LTN58	INU	Litton
452080-04	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-04-02	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-04-02-20	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-04-02-28	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-04-13	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-04-19-42	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-04-20	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-04-28	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-02-29-29	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-02-29-29	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-02-29-29	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-02-33-61	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-02-48-50	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05--02-79-29	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-04	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-10	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-10-20	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-10-21	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-11	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-12-29	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-12-29	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-13	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-14	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton

LRU Repair/Overhaul Capability List 2017

System P/N	Description	Product	Key Word	OEM
452080-05-14	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-19-42	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-20	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-28	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-30-46	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-30-46	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-33-61	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-56	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-56	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452080-05-85-15	LTN-72 Inertial Navigation Unit	LTN72	INU	Litton
452090-01	LTN 72 Control Display Unit	LTN72	CDU	Litton
452090-01-11	LTN 72R Control Display Unit	LTN72	CDU	Litton
452090-02	LTN 72 Control Display Unit	LTN72	CDU	Litton
452100-01	LTN-72/92 Mode Select Unit	LTN72/92	MSU	Litton
452100-01BLK	LTN-72/92 Mode Select Unit	LTN72/92	MSU	Litton
452100-02	LTN-72/92 Mode Select Unit	LTN72/92	MSU	Litton
452100-02-02	LTN-72/92 Mode Select Unit	LTN72/92	MSU	Litton
452100-02-03	LTN-72/92 Mode Select Unit	LTN72/92	MSU	Litton
452100-02-04	LTN-72/92 Mode Select Unit	LTN72/92	MSU	Litton
452100-02-1	LTN-72/92 Mode Select Unit	LTN72/92	MSU	Litton
452100-02BLK	LTN-72/92 Mode Select Unit	LTN72/92	MSU	Litton
454620-01	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-01	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-02	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-02-12-58	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-02-28	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-02-33-50	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-02-48-50	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-16-19	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-20	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-28	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-30-00	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-34-35	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-38-53	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-40-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-40-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-40-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-40-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-41-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-41-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-41-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-42-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-42-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-42-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-43-51	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-48-51	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-500	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-500-20	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-500-28	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-53-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-54-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-553-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton

LRU Repair/Overhaul Capability List 2017

System P/N	Description	Product	Key Word	OEM
454620-01-554-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-555-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-55-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-556-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-557-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-558-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-56-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-57-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454620-01-58-62	LTN-72R Inertial Navigation Unit	LTN72	INU	Litton
454640-01	LTN 72R Control Display Unit	LTN72	CDU	Litton
454640-01-02	LTN 72R Control Display Unit	LTN72	CDU	Litton
454640-01-03	LTN 72R Control Display Unit	LTN72	CDU	Litton
454640-01-07	LTN 72R Control Display Unit	LTN72	CDU	Litton
454640-01-08	LTN 72R Control Display Unit	LTN72	CDU	Litton
454640-01-10	LTN 72R Control Display Unit	LTN72	CDU	Litton
456660-02-01	Align Display Unit	LTN72	ADU	Litton
457300-04-012	Omega RPU	OMEGA	RPU	Litton
458100-02-02	Omega Control Display Unit	OMEGA	CDU	Litton
458900-03	LTN 72RL LED Control Display Unit	LTN72	CDU	Litton
458900-03-03	LTN 72RL LED Control Display Unit	LTN72	CDU	Litton
458900-04	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-05	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-06	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-06-01	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-06-02	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-07	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-08-01	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-08-02	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-09-01	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-09-02	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-10-01	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
458900-11-01	LTN 92 LED Control Display Unit	LTN92	ISDU	Litton
460500-03-02-12-55-3A	LTN-72RL Inertial Navigation Unit	LTN72	INU	Litton
460500-03-02-12-55-8S	LTN-72RL Inertial Navigation Unit	LTN72	INU	Litton
460500-03-02-13-73-3A	LTN-72RL Inertial Navigation Unit	LTN72	INU	Litton
460500-03-02-13-73-5K	LTN-72RL Inertial Navigation Unit	LTN72	INU	Litton
460500-03-02-13-73-6S	LTN-72RL Inertial Navigation Unit	LTN72	INU	Litton
460500-03-05-48	LTN-72RL Inertial Navigation Unit	LTN72	INU	Litton
460500-03-49-3A	LTN-72RL Inertial Navigation Unit	LTN72	INU	Litton
460500-03-49-8A	LTN-72RL Inertial Navigation Unit	LTN72	INU	Litton
460500-03-49-8S	LTN-72RL Inertial Navigation Unit	LTN72	INU	Litton
460500-03-500-49-3A	LTN-72RL Inertial Navigation Unit	LTN72	INU	Litton
460600-xx	Align Display Unit	LTN72	ADU	Litton
461800-0200-2201	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
461800-0200-2203	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
461800-02-08-116	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
461800-0208-1606	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
461800-02-122	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
461800-0300-2201	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
461800-0300-2202	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
461800-0300-2203	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
461800-03-222	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton

LRU Repair/Overhaul Capability List 2017

System P/N	Description	Product	Key Word	OEM
461800-04-08-116	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
461800-0408-1606	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
461800-04-122	LTN90-100 Inertial Reference Unit	LTN90-100	IRU	Litton
463001-0200-0411	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-02-04	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-0400-0502	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-04-02-12	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-04-05	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-0500-0411	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-05-04	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-6000-0412	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-6000-0413	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-6110-0412	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-6130-0413	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7000-0503	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7000-0504	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7000-0505	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7000-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7000-1500	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7000-1501	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7120-0503	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7130-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7130-1501	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7130-1502	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7140-0504	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7140-1500	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7160-0505	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7170-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7180-0505	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7180-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7221-0503	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7233-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7235-1501	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7235-1502	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7241-0504	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7252-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7262-0505	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-7285-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8000-0412	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8000-0413	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8000-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8110-0412	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8130-0413	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8130-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8130-1502	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8170-0413	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8170-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8180-0413	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8180-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8233-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8235-1501	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-8235-1502	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton

LRU Repair/Overhaul Capability List 2017

System P/N	Description	Product	Key Word	OEM
463001-9000-0413	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-9180-0413	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
463001-9180-0506	LTN-92 Inertial Navigation Unit	LTN92	INU	Litton
663450-07	LTN-51 Inertial Navigation Unit	LTN51	INU	Litton
663450-08	LTN-51 Inertial Navigation Unit	LTN51	INU	Litton
663450-08-02	LTN-51 Inertial Navigation Unit	LTN51	INU	Litton
663450-100-01	LTN-51 Inertial Navigation Unit	LTN51	INU	Litton
663450-14	LTN-51 Inertial Navigation Unit	LTN51	INU	Litton
663550-02	LTN 51 Control Display Unit	LTN51	CDU	Litton
663550-03	LTN 51 Control Display Unit	LTN51	CDU	Litton
663550-03-100	LTN 51 Control Display Unit	LTN51	CDU	Litton
663550-04	LTN 51 Control Display Unit	LTN51	CDU	Litton
663550-04-301	LTN 51 Control Display Unit	LTN51	CDU	Litton
663550-05	LTN 51 Control Display Unit	LTN51	CDU	Litton
663550-05-100	LTN 51 Control Display Unit	LTN51	CDU	Litton
663550-08	LTN 51 Control Display Unit	LTN51	CDU	Litton
663570-01	LTN 51 Mode Select Unit	LTN51	MSU	Litton
663570-02	LTN 51 Mode Select Unit	LTN51	MSU	Litton
663570-03	LTN 51 Mode Select Unit	LTN51	MSU	Litton
7881390-011	Carousel Control Display Unit	CIV	CDU	Delco
7883450-041	CIV Inertial Navigation Unit	CIV	INU	Delco
7883450-521	CIV II Inertial Navigation Unit	CIV	INU	Delco
7883450-531	CIV IID Inertial Navigation Unit	CIV	INU	Delco
7883460-031	Carousel Control Display Unit	CIV	CDU	Delco
7883470-011	Carousel Mode Select Unit	CIV	MSU	Delco
7886580-011	CIV A Inertial Navigation Unit	CIV	INU	Delco
7890860-011	CIV A II Inertial Navigation Unit	CIV	INU	Delco
7890860-021	CIV A III Inertial Navigation Unit	CIV	INU	Delco
7890860-511	CIV A IV Inertial Navigation Unit	CIV	INU	Delco
879010-1	CN 1561/ASN-130A IMU	ASN-130A	IMU	Litton
879010-2	CN 1561/ASN-130A IMU	ASN-130A	IMU	Litton
886401-1	AN/ASN-130A IMU	ASN-130A	IMU	Litton
886401-4	AN/ASN-130A IMU	ASN-130A	IMU	Litton